



CITY

60092



1



2



3



4





+



1





2




3






1




2






1





1x

2






1x

3




8



1x


4





2x

5







1x



1x

6






1x



1x

7





1x



1x




1x



1x

8


1



2



3






1x



2x

9





1x



1x

1



1x



5x



2x

2




5x



2x




10





1x

11






1x



1x

12





1x



1x

1




1x



1x

2






1x

3



2x


4






4x

5




13





2x

14





CITY



60090



60091



60092



60093



60095

LEGO.COM/CITY



1x
6004491



1x
303201



2x
6032360



3x
6110028



4x
6110023



1x
4118981



1x
4651524



2x
609121



1x
302321



1x
6113983



2x
4298617



4x
6107179



1x
4599453



1x
4142865



2x
6069163



2x
371023



2x
302023



2x
346023



6x
4143005



2x
4206482



2x
4514553



4x
300924



2x
4216656



2x
6020505



1x
6079007



1x
6079001



4x
6105614



2x
241224



2x
306924



1x
371024



2x
243124



1x
379524



1x
403224



2x
4593677



2x
74156



1x
4651443



1x
4261572



1x
6100222



2x
4490142



2x
6110040



2x
6100888



1x
300526



2x
6088638



2x
4167106



7x
4121715



1x
4494850



1x
374726



2x
241226



1x
302226



3x
4565323



2x
366626



2x
4610948



2x
4632571



4x
4526982



2x
4225201



1x
4650145



1x
4523339



5x
6018805



1x
4531412



1x
4106552



1x
4187209



1x
614026



2x
4143372

26



2x
6107232




2x
6107228



8x
6006739



1x
4129572



1x
303426



1x
4181144



2x
4558850



4x
6112605



2x
6059027



1x
4119479



1x
4217436



1x
3000841



1x
3005741



1x
4113954



1x
4581214



2x
4499885



2x
4499885



1x
4624369



1x
4162916



1x
6021978



1x
4119482



17x
4650498



1x
4246957



1x
4530712



1x
6030845



2x
6055631

5



1x
6113985



1x
6005772



1x
4211163



1x
4533101



1x
4558953



2x
4535764



2x
4211614



2x
4211396



2x
4654582



1x
4211840



2x
4515351



2x
4211492




2x
4211491



2x
4221775



2x
4494475



1x
4216709



1x
4211060



1x
4211085



2x
4497253



4x
4296788



4x
4211097



3x
4211024



3x
4210637



2x
4587212



1x
4210639



2x
6047417



1x
6055313



2x
4500608



1x
6107827



2x
4260124



4x
4540386



1x
6063277



4x
6106025



1x
4211002



1x
4549999



4x
4210998



1x
6044722



1x
6031896



1x
6015890



2x
4210694



2x
6100030



2x
6083620

4



1x
6012451



5x
4649422



3x
6008483



3x
6030198



2x
6051823



Customer Service

Kundenservice

Service Consommateurs

Servicio Al Consumidor

LEGO.com/service or dial



: 00800 5346 5555

: 1-800-422-5346